

## CHEMICAL SPILL KIT REQUIREMENTS – LAB LOCATIONS

Every store with a lab that maintains a chemical inventory must be equipped with a chemical spill kit (control station). The spill kit should be stored in a cool, dry location and with a Spill Control sign posted near the kit. The contents of the spill control station should be inspected monthly during the “store monthly self-inspection”.

### Spill Control Station Contents

A chemical spill control station must be maintained in all labs. The minimum required contents depend on the lab type.

### Full labs

Full labs should have the following items:

- 2 ½ gallon bucket for waste materials  
(To be kept empty and only to be used to hold waste materials)
- 5-gallon bucket with threaded lid or a stacking drawer system (For supplies)

### Supplies

- Cob-Dry – 10 lbs for full service labs
- Scoop
- 2 pair of nitrile gloves
- 2 pair of chemical protective goggles
- Whisk broom and dust pan kit
- Spill Clean-up instructions (hard copy)
- Syringe (only for full labs, to be used as needed to clear blockage in the Clean and Coat bowls)

### Set Up Instructions

- (1) Apply a “Spill Control Station” label to the larger tote (or the front of the drawers).
- (2) Pour / place the Cob-Dry into the bottom of the larger tote (or in the bottom drawer).
- (3) Place the scoop on top of the Cob-Dry.
- (4) Place the following items in baggies:
  - Gloves
  - Goggles
  - Broom/dust pan
  - Syringe
- (5) Place the bagged supplies into the 5-gallon supply bucket on top of the scoop and Cob-Dri (or in an upper drawer).
- (6) Latch the large tote closed.
- (7) Place the 2 ½ - gallon bucket on top of the tote.



**Urgent Care labs**

Urgent Care labs should have the following items:

- 2 ½ gallon bucket for both storage and waste materials

Supplies

- 1 pair of nitrile gloves
- 1 pair of chemical protective goggles
- Spill Clean-up instructions (hard copy)
- Paper towels

**Set Up Instructions**

- (1) Apply a “Spill Control Station” label to the outside of the bucket
- (2) Place the following items in the bucket:
  - Gloves
  - Goggles
  - Paper towels
- (3) Close the bucket.

**Purchasing information**

Below is a list of the various Spill Kit items.

Use the CP Workbook to identify the most up-to-date CP numbers for each item when ordering.

<b>description (use)</b>
Broom/dust pan for spill kit
Bucket, 2 1/2-gallon (Haz Waste Container)
Bucket, 5-gallon (Spill Control Station)
Cob-Dry (Absorbent) - 10 lb
Cob-Dry (Absorbent) - 5 lb
Spill Control Station Label
Goggles
Syringe (full labs only)
Absorbent spill pads (10x14 - 25 per pack) - optional