

Appendix 1 – TSB 16/18 Revised MHE decal fitment

Equipment required:

- Battery case warning decal
- Fixt Foaming Panel Cleaner – Part Number FX081208
- Clean cloth or paper towel
- Application squeegee or any item with a straight soft edge

Step 1

Use the Foaming Panel cleaner and cloth to clean the area where the decal is to be applied, ensuring that any stuck on particles are completely removed.

Step 2

Once the area is clean and dry, peel the decal from its backing tape and apply to the desired area. Start at one edge of the decal and apply in an even fashion across the vinyl to the opposite edge. This will limit the amount of air that can be trapped behind the decal. When applying always ensure that the decal is central to the gate top panels on the moving deck and in the same position as the 'No MHE' decal you've removed on the lower deck as pictured in the examples below.

Step 3

Use the soft side of the squeegee or application tool to push any air bubbles to the closest edge of the decal so they can be released. If air bubbles are stubborn you can use a scalpel blade or a pin to prick a tiny hole in the bubble and force the air out with your finger. Ensure that all the adhesive is attached to the surface.

Lower deck – N/S/R panel & O/S/R panel decals to be removed



Lower deck – N/S/R panel and O/S/R panel revised decals fitted



Moving Deck – N/S/R decal to be removed – not all trailers have the same decal fitted on the O/S/R panel but if there is one this MUST be removed as well.



Moving deck – N/S/R Open gate and O/S/R Open gate revised decals fitted (please ensure the bi-fold gates are closed as pictured and the decals fitted so they are clearly visible when in this position).

